



GREEN WIRE

ATTENTION : IF YOU WANT TO SYNCHRONIZE STROBE BETWEEN BOTH LIGHTS YOU SHOULD RUN A WIRE CONNECTING ALL GREEN WIRES FROM ONE LIGHT TO THE OTHER. **TO AVOID DAMAGE**, DO NOT CONNECT GREEN WIRE TO 12VTS OR GROUND.

INSTALLATION INSTRUCTIONS

SAS-130 Series SIGMA Led

Not TSO equipment

Tech support